GLACIER BAY

Item # 1000 041 318
Model # SH-72LED-07

USE AND CARE GUIDE

LED TEMPERATURE INDICATING HANDHELD SHOWER



THANK YOU

We appreciate the trust and confidence you have placed in Glacier Bay through the purchase of this LED Temperature Indicating Handheld Shower. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs.

Warranty

WHAT IS COVERED

This warrants the original purchaser that this product will be free of manufacturing defects under normal domestic use for the life of the product beginning from the original date of purchase. Present warranty does not extend to anyone except the first purchaser at retail. Also, original sales receipt must be obtained in order for the warranty to be valid. To obtain warranty service, contact the retailer from which the product was purchased.

WHAT IS NOT COVERED

Present warranty excludes damages resulting in whole or part from installation error, product abuse, misuse, neglect, any alterations to products, improper maintenance, abrasives, corrosion and / or accidents, whether caused performed by a professional or anyone else.

Limited Life Time Warranty does not apply to products used in or used for industrial, commercial or business environment or purpose. The Limited Warranty is valid for 1 year under these conditions.

Any and all LED bulbs replacement are not included in the warranty.

Any and all faucets and accessories that are subject to any type of harsh abrasive, such as detergents or window cleaners, will not be covered under the warranty. The manufacturer is not responsible for any labor or shipping charges, or damages whatsoever incurred in whole or in part from installation, removal, re-installation, repair or replacement of any product or part, as well as any incidental or consequential damages, expenses, losses, direct or indirect, arising from any cause whatsoever.

GLACIER BAY™

Questions, problems, missing parts? Before returning to the store,
call Glacier Bay Customer Service
8 a.m.-6 p.m., EST, Monday-Friday

1-855-HD-HAMPTON

HOMEDEPOT.COM

Safety Information

WARNING: Do not use the LED color as an accurate thermometer. Use your palm to test the water temperature before you take your bath.

NOTE: This hand shower unit is recommended to install and use with automatic compensating valve(s).

Specifications

- When the water temperature is lower than 77°F, the LED color displayed is Blue.
- When the water temperature is between 78°F to 95°F, the LED color displayed is Green.
- When the water temperature is between 96°F to 113°F, the LED color displayed is Red.
- When the water temperature is higher than 114°F, the LED color displayed is Green and Red flashing alternatively.

Care and Cleaning

To preserve the beauty of this product, wash the product with a soft liquid non-abrasive soap, warm water, and a soft cloth.

Never use abrasive, chemical, corrosive, powder or strong cleaners, including toothpaste, detergents, window cleaners and disinfectants. Use of these items will void your warranty.

Pre-Installation

TOOLS REQUIRED

Adjustable Wrench

Thread Sealant Tape

PACKAGE CONTENTS



Part	Description	Quantity
A	Clip	1
B	Hand Shower	1
C	Check Valves (pre-installed)	1

Part	Description	Quantity
D	Washer	2
E	Shower Hose	1
F	Thread Sealant Tape	1

Installation

1 Removing the Existing Showerhead

IMPORTANT: Shut off the water supply prior to removing the existing fixture.

- ☐ Remove the old showerhead with a wrench.
- ☐ Clean the shower arm threads.



2 Installing the Diverter

- ☐ Apply new thread sealant tape (F) to the shower arm.
- ☐ Hand tighten the clip (A) (clockwise) onto the shower arm.



3 Attaching the Hose

- ☐ Attach one end of the hand shower hose (E) and a washer (D) to the bottom of the 1/2" outlet on the clip (A).



4 Installing the Handshower

Attach the other end of the hand shower hose (E) and a washer (D) to the hand shower (B).

CAUTION: Do not overtighten the nut/gasket.



5 Installing the Handheld Shower

- ☐ Set the hand shower (B) into the hand shower holder on the clip (A).

NOTE: Inspect the check valve(s) on the original fixture. If damaged or missing, please contact the original manufacturer and replace with new check valves to avoid water back flow.